



三菱 10X-883 3バンド・トランジスタ・ラジオ




MITSUBISHI Model 10X-883




主回調 FINE TUNER

MAIN TUNER



トランス類底視図
BOTTOM VIEW OF TRANSFORMERS



- NOTE:
1. S₁~S₁₂ are band select switches, and now indicates MW connection.
 2. S₁₃~S₁₄ are DX-HiFi select switches.
 3. All resistors are ohms unless otherwise specified. K=1000 ohm
 4. All capacitors are in microfarads otherwise specified. P=10⁻⁶ microfarads.
 5. Voltage measurements are made with a VTVM from point indicated to battery (+) terminal.
 6. With no signal and at minimum volume control total battery drain should be approx 18mA