


ナショナル MODEL CM-615

CONV
6BE6

1 F
6BA6

2nd DET. AVC & AF
6AV6

OUTPUT
6AR5



注: 現在1 - SW (S1 S2 S3 S4) は PHONO LOW の位置に
 右へ 30° づつ PHONO MEDIUM PHONO FULL
 OFF. RADIO FULL. RADIO MEDIUM. RADIO LOW
 と動く

LOW. MEDIUM. FULL

RC-186W @ 05160

Edit by JA3GZP