

NATIONAL HG-700

2SA103CA

0A70Y

2SA103CA


2SA102BA

UA70X

2SB173B

2SB175B

2SB172A×2



- (1) Band selection switch ($S_1 \sim S_9$) is combined and now at MW position. Turning the switch to P, it is Phono-graph and to S, is SW position.
- (2) Battery ON-OFF switch (S_{11}) is combined VR, and now in OFF.
- (3) Switch S_{11} is Motor ON-OFF switch and in OFF now.