


NATIONAL SG-710 A

TR₁
2SB117
1st AF Amp

TR₂
2SB175
2nd AF Amp

TR₃, TR₄
2SB176 × 2
Power out put



R	R ₁ , VR ₁	VR ₂	R ₂ , R ₃ , R ₄	R ₅ , R ₆ , R ₇ , VR ₃	R ₈	R ₁₁	R ₉	R ₁₃	R ₁₀	R ₁₂	
C		C ₁	C ₂	C ₃	C ₄	C ₅	C ₁₀	C ₆	C ₇	C ₈	C ₉

S₁, S₂: Selector switch in "OFF" Position.

S₃: Power source switch in "OFF" Position.