



- SELECTOR SWITCH**
- 1 MPX
 - 2 FM
 - 3 AM
 - 4 PHONO
 - 5 TAPE
 - 6 AUX
- MODE SW-TCH**
- 1 STEREO R
 - 2 STEREO N
 - 3 MONO A
 - 4 MONO B
 - 5 MONO A+B
- SL-SWITCH**
- SL-1 TAPE MONITOR
 - SL-2 HIGH CUT FILTER
 - SL-3 LOUDNESS
 - SL-4 LOW CUT FILTER
 - SL-5 IMPEDANCE SELECTOR
 - SL-6 PHASE SELECTOR
 - SL-7 SENSITIVITY SELECTOR
 - SL-8 BROAD-SHARP AFC SWITCH
 - SL-9 VOLTAGE SELECTOR
 - SW-1 POWER SWITCH (PUSH TYPE)
- VOLUME**
- VR₁ AUX LEVEL CONTROL
 - VR₂ TREBLE CONTROL
 - VR₃ BASS CONTROL
 - VR₄ BALANCE CONTROL
 - VR₅ MAIN VOLUME
 - VR₆ VR₇ 7189-A
 - VR₈ BALANCE CONTROL
 - VR₉ 7189-A BIAS CONTROL
 - VR₁₀ SEPARATION CONTROL

パイオニア SM-600

