

SONY 7F-81W

Q101 2SC629


Q102 2SK23

Q103 2SC403A

Q104 2SC403A

D101 1S1806

FM TUNER BLOCK (FMC-127W1)



D301 IT26

D306 IT26

D302 IT23G

D303 IT240

D304,305 IT26

Q301 2SC403A

Q302 2SC403A

Q303 2SC403A

Q304 2SC403A

Service Guide