


# SONY 4R-51



Voltage and Current Distribution Chart at Zero Signal

