

# SONY 8R-43

X<sub>1</sub> 2SA330

X<sub>2</sub> 2SA202

X<sub>3</sub> 2SA203

D<sub>1</sub> 1S426

X<sub>4</sub> 2SB186

X<sub>5,6</sub> 2SB187 × 2

