


# STANDARD SR-L555F

- |                    |                      |                     |                        |                                     |                                     |                     |                     |                     |                          |                       |
|--------------------|----------------------|---------------------|------------------------|-------------------------------------|-------------------------------------|---------------------|---------------------|---------------------|--------------------------|-----------------------|
| Q1 25A343<br>FM-RF | Q2 25A343<br>FM-CONV | Q3 25B175<br>FM-AFC | Q4 25A234<br>FM-IF 1ST | Q5 25A234<br>FM-IF 2ND<br>AM-IF 1ST | Q6 25A234<br>FM-IF 3RD<br>AM-IF 2ND | Q11 25B75<br>AF-1ST | Q12 25B75<br>AF-2ND | Q13 25B75<br>DRIVER | Q14,15 25B156X2<br>POWER | Q16 25A70<br>AM CONV. |
|--------------------|----------------------|---------------------|------------------------|-------------------------------------|-------------------------------------|---------------------|---------------------|---------------------|--------------------------|-----------------------|



STANDARD SERVICE DATA